



# MyFlame

## CONTROL SYSTEM











For LED Electric Fires



## APP SET UP




## APP SET UP



## MANUAL OR AUTOMATIC CONTROLS




## SET C/F°




## MANUAL HEATING ADJUSTMENT




## TIMER




### FLAME ADJUSTMENT - FLAME & DOWNLIGHT









### FLAME ADJUSTMENT - FUEL BED



### FLAME ADJUSTMENT - AMBIENT MOOD LIGHT



## SET FLAME PROGRAM



## SET HEATER PROGRAM

**1**

eReflex

Advanced Menu

GAZCO

HOME

FLAME

GLOWING EMBERS

AMBIENT LIGHT

SET FLAME PROGRAM

SET HEATER PROGRAM

TEMPERATURE UNIT

MANU HIGH

**2**

10:16 18%

Set Weekly Timer For Heater:

| Start | End   | Temp |
|-------|-------|------|
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |

Up to 4 time periods a day, 3 different weekly schedules

Repeat: Mon Sun

| Start | End   | Temp |
|-------|-------|------|
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |

Cancel Save

**3**

10:17 18%

Set Weekly Timer For Heater:

| Start | End   | Temp |
|-------|-------|------|
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |

Repeat for:

Mon Tues Wed Thur Fri Sat Sun

**1** Start End

06 07

07 : 00 **2** 08 : 00

08 01 09 01

Cancel Save

**4**

10:17 18%

Set Weekly Timer For Heater:

| Start | End   | Temp |
|-------|-------|------|
| 07:00 | 08:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |

Repeat for:

Mon Tues Wed Thur Fri Sat Sun

| Start | End   | Temp |
|-------|-------|------|
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |

Cancel Save

**5**

10:17 18%

Set Weekly Timer For Heater:

| Start | End   | Temp |
|-------|-------|------|
| 07:00 | 08:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |

Repeat for:

Mon Tues Wed Thur Fri Sat Sun

Set Temperature

**1** 6°C **2** 7°C

Cancel Save

**6**

08:55

1

| Start | End   | Temp |
|-------|-------|------|
| 07:30 | 08:30 | 10°C |
| 12:00 | 13:00 | 10°C |
| 18:00 | 22:00 | 10°C |
| 00:00 | 00:00 | 0°C  |

Repeat for:

Mon Wed Thur Fri Sat Sun

| Start | End   | Temp |
|-------|-------|------|
| 00:00 | 00:00 | 0°C  |
| 00:00 | 00:00 | 0°C  |

Cancel Save

**7**

08:57

Mon Tues Wed Thur Fri Sat Sun

| Start | End   | Temp |
|-------|-------|------|
| 07:30 | 09:00 | 10°C |
| 12:00 | 13:00 | 10°C |
| 18:00 | 22:00 | 10°C |
| 00:00 | 00:00 | 0°C  |

Repeat for:


Mon Tues Wed Thur Sat Sun

**1**




| Start | End   | Temp |
|-------|-------|------|
| 00:00 | 00:00 | 10°C |

Cancel **2** Save

## DEVICE INFORMATION



## WIFI





**FOR ENQUIRIES IN THE U.K (EXCLUDING NI):**

**Gazco Limited, Spitfire Avenue, Skypark, Clyst Honiton, Exeter, Devon, EX5 2FR**

**Tel: (01392) 261900 E-mail: [info@gazco.com](mailto:info@gazco.com)**

**FOR ENQUIRIES IN EUROPE (INCLUDING NI):**

**Stovax Heating Group (NI) Ltd (Comp reg NI675194), 40 Linenhall Street, Belfast, BT2 8BA**

**DX 400 NR Belfast Tel: +44 (0)1392 261990 E-mail: [northernireland@gazco.com](mailto:northernireland@gazco.com)**

